



Warrior, Inc.
11100 SW Industrial Way
Tualatin, OR 97062
Phone: (888) 220-6861
Fax: (503) 692-0364
customerservice@warriorproducts.com
www.warriorproducts.com

FJC TAIL GATE LOWER COVER
INSTALLATION INSTRUCTIONS
3930/3930PC/S3930

INSTALLATION:

1. Begin by removing the license plate and setting it aside.
2. Next, remove the 2 piece factory rear tail gate moulding. There is a small bolt on the right corner of each piece. After the bolts have been removed, utilize a trim removal tool and pop the moulding off of the tail gate. Remove any inserts that remain in the tail gate.
3. Install the square plastic inserts into the holes on the tail gate.
4. A length of rubber trim is included in the kit. Install the trim along the upper left edge of the Warrior Tail Gate Cover, continuing down into the spare cut out and ending at the starting edge of the license plate light cut out. Trim the ends to fit the length needed.
5. Set the tail gate cover onto the tailgate, lining up the holes with the inserts underneath. Begin threading the screws through the cover, but do not final tighten until all the screws have been installed. Once you're satisfied with the positioning, snug up the screws.
6. Install the license plate onto the studs utilizing the hardware provided.
7. Your installation is now complete.

If you need further assistance installing your product, please contact us by email at techsupport@warriorproducts.com or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS