



Warrior, Inc.
11100 SW Industrial Way
Tualatin, OR 97062
Phone: (888) 220-6861
Fax: (503) 692-0364
customerservice@warriorproducts.com
www.warriorproducts.com

JEEP XJ / 87 – 02 YJ + TJ STEERING BOX BRACE

P/N: 894 / 896 / 898

INSTALLATION INSTRUCTIONS

IMPORTANT NOTE:

Your new steering box brace is designed for power steering equipped vehicles only. It will likely not fit applications with manual steering boxes.

INSTALLATION:

1. Bolt the cross bar steering brace and clamp to the steering box loosely so you can mark the frame for drilling the four (4) holes.
2. The self tapping 3/8" screws require a drill of at least 9/32". Drill all four holes after you are sure of proper alignment. On the #894 the two (2) self tapping screws go into the box frame and the two (2) 5/16" bolts and nuts are mounted to the pinch weld. Drill these two holes 11/32"
3. Install complete unit using the four (4) bolts to the frame and install "C" brackets around bottom of steering bracket using bolts provided with lock nut provided, make sure Pitman Arm has clearance to turn without interference of bracket.
4. Tighten all bolts. Caution: do not over tighten self tapping screws.
5. After a test drive, verify that all bolts are tight.

If you need further assistance installing your product, please contact us by email at customerservice@warriorproducts.com or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS



WARRIORPRODUCTS.COM

