



Warrior, Inc.
11100 SW Industrial Way
Tualatin, OR 97062
Phone: (888) 220-6861
Fax: (503) 692-0364
customerservice@warriorproducts.com
www.warriorproducts.com

2003 – 2006 JEEP WRANGLER TJ / LJ STEERING BOX BRACE

P/N: 893

INSTALLATION INSTRUCTIONS

NOTE:

Your new steering box brace bolts between steering box neck, next to the Pitman Arm and the opposite side frame rail.

INSTALLATION:

1. Bolt the flat plate with 4 holes, provided with kit, to the bottom of the steering box, above the Pitman Arm. The new bolts provided must have lock tight applied to the threads. This is mandatory. The "U" opening faces towards the driver side. Tighten all four bolts.
2. Install complete cross bar using the four (4) self tapping screws to the frame. Leave bolt on steering box tube loose at steering box until the 4 self tapping screws have been installed. The screws can self drill or, for ease of installation, a pilot hole of 9/32" can be drilled.
3. Tighten all bolts. Caution: do not over tighten self tapping screws.
4. After a test drive, verify that all bolts are tight.

If you need further assistance installing your product, please contact us by email at customerservice@warriorproducts.com or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS



WARRIORPRODUCTS.COM

