



Warrior, Inc.
11100 SW Industrial Way
Tualatin, OR 97062
Phone: (888) 220-6861
Fax: (503) 692-0364
customerservice@warriorproducts.com
www.warriorproducts.com

JEEP CJ7 / CJ8 STANDARD REAR BUMPER WITH RECEIVER

INSTALLATION INSTRUCTIONS

P/N: 520

1. Remove stock "Bumperettes". Retain bolts, washers, and nuts for installing your new Bumper.
2. Install Bumper using bolts removed in #1 above. Tighten to manufacturer's suggested torque. Be sure there is a washer under the bolt head and between the nut and the frame. (Washers are not provided)
3. The two bolts and lock washers provided are to be used on the bottom of the Bumper. Tighten bolts to 50 ft. lbs. torque.

If you need further assistance installing your product, please contact us by email at customerservice@warriorproducts.com or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS



WARRIORPRODUCTS.COM

