



Warrior, Inc.
11100 SW Industrial Way
Tualatin, OR 97062
Phone: (888) 220-6861
Fax: (503) 692-0364
customerservice@warriorproducts.com
www.warriorproducts.com

JEEP CJ / YJ / TJ / LJ ROCK CRAWLER FRONT BUMPER

P/N: 570 / 571 / 57050 / 57051 / 578 / 579 / 57058 / 57059

INSTALLATION INSTRUCTIONS

IMPORTANT NOTE:

These bumpers are designed to fit over factory front frame horns and use existing factory mounting holes and hardware.

1. Remove your existing bumper from your vehicle. Save all bolts as you will need them later for installing your new bumper.
2. If you have lights mounted on your old bumper and wish to remount them on your new bumper, mark bumper for drilling and mount them at this time.
3. Install new bumper with factory hardware removed in step one. There are two square washers provided. They should be placed on the top of the frame and under the factory tow hook for proper spacing.
4. Reinstall license plate on the passenger side of the bumper using factory bolts.
5. After initial test drive, check all bolts for tightness.

If you need further assistance installing your product, please contact us by email at customerservice@warriorproducts.com or call us at (888) 220-6861.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS



WARRIORPRODUCTS.COM

