



Warrior, Inc.
11100 SW Industrial Way
Tualatin, OR 97062
Phone: (888) 220-6861
Fax: (503) 692-0364
customerservice@warriorproducts.com
www.warriorproducts.com

1982 – 1995 CJ7/YJ FULL DOOR INSERT PANEL

INSTALLATION INSTRUCTIONS

P/N: 60750 / 90750 / 90750PC / S90750

INSTALLATION INSTRUCTIONS:

1. Remove inner factory grab handle and window crank handle.
2. Remove the lower inner panel by prying with long screwdriver. Check to make sure that you did not leave any black plastic fasteners attached to the door.
3. Put the Warrior inner panel into place on the door making sure that it is under the OEM upper panel and centered on the door. At this time, mark all of the rivet holes through the panel for drilling.
4. Remove the panel from the door. If you are going to use the “pop” rivets supplied, drill the holes using a 3/16” drill bit. If you choose to use sheet metal screws, or some other attachment method (not included) use a drill bit appropriate for the size of screw you choose to use.
5. Install your new Warrior inner panel using the pop rivets supplied or sheet metal screws. Make sure that you have the panel situated under the OEM upper panel.
6. Reinstall the window crank handle and the grab handle removed in step #1. You can use Warrior Products’ optional grab handle (part # WAR 90756) if you prefer.

THANK YOU FOR PURCHASING WARRIOR PRODUCTS

If you need further assistance installing your product, please contact us by email at customerservice@warriorproducts.com or call us at (888) 220-6861.



WARRIORPRODUCTS.COM

